
Aery32 Reference Guide

Release 0.3.0

Muiku Oy

September 09, 2012

CONTENTS

1	Getting Started	1
1.1	Basics of the embedded software	1
2	Project structure – where things go?	3
2.1	Main source file, <code>main.cpp</code>	3
2.2	Board specific functions, <code>board.h</code> and <code>board.cpp</code>	4
2.3	Aery32 library	4
2.4	Examples	4
3	The build system	5
3.1	Chip programming	5
3.2	How to add new source files to the project	6
3.3	Compile with debug statements	6
4	Delay functions, <code>#include <aery32/delay.h></code>	7
4.1	Use RTC for long delays	7
5	UC3A0/1 system clocks described	9
5.1	Main clock means the CPU clock	9
6	Module functions	11
6.1	Naming convention and the calling order	11
6.2	Global variables and error handling	12
6.3	Analog-to-digital conversion, <code>#include <aery32/adc.h></code>	12
6.4	Flash Controller, <code>#include <aery32/flashc.h></code>	13
6.5	General Periheral Input/Output, <code>#include <aery32/gpio.h></code>	14
6.6	Interrupt Controller, <code>#include <aery32/intc.h></code>	16
6.7	Power Manager, <code>#include <aery32/pm.h></code>	16
6.8	Pulse Width Modulation, <code>#include <aery32/pwm.h></code>	19
6.9	Real-time Counter, <code>#include <aery32/rtc.h></code>	22
6.10	Serial Peripheral Bus, <code>#include <aery32/spi.h></code>	22
7	Contributor’s guide	25
7.1	Sending a pull request (creating a patch)	25
7.2	Coding standards	25
7.3	Writing the documentation	26
8	Indices and tables	29

GETTING STARTED

The best way to get started is to follow the Quick Start from Aery32's homepage, <http://www.aery32.com/pages/quick-start>.

1.1 Basics of the embedded software

```
1  #include "board.h"
2  #include <aery32/all.h>
3
4  using namespace aery;
5
6  int main(void)
7  {
8      /* Put your application initialization sequence here */
9      init_board();
10     gpio_init_pin(LED, GPIO_OUTPUT);
11
12     /* All done. Turn the LED on. */
13     gpio_set_pin_high(LED);
14
15     for(;;) {
16         /* Put your application code here */
17
18     }
19
20     return 0;
21 }
```

Above you can see a basic embedded software coded by C++ programming language for Aery32. This piece of source code can be found from the `main.cpp` source file. The `main()` function at line 6 is the first function to execute when the program starts – thus it is called *main*. The `void` keyword inside the brackets of the function, tells that the function does not take any arguments. The main function hardly ever takes arguments in embedded software, so this is a very common situation.

The `int` keyword, before the main function, indicates that the function will return integer type variable. Again, in the real life embedded software, it is very common that there is no use for the return value. The return type has been specified here to be integer type, instead of making it `void`, only to keep the compiler happy. Otherwise the compiler would give a warning, which we do not want to see. For the sake of consistency the return value has been set zero at line 20, but the running application should never reach that far, or if it does, some serious error has occurred. Although there is no use for the input arguments and the return value of the main function, the other functions, of course, may have arguments and can return values which are relevant.

1.1.1 Where to put the application code?

If the program should never reach the line 20, you might guess where the code of actual application is placed. Correct! It is placed inside of the infinite `for(;;)` loop. This loop goes on and on accomplish the code inside of it until the power is switched off. In this particular software there is only a comment line inside of the loop, so pretty much nothing is happening. What happens has been done at lines 9, 10 and 13. These functions will be executed only once, because those do not fall into the infinite for-loop. Furthermore, these function calls comes with the Aery32 Software Framework. The first one initializes the board, which is pretty much about starting the 12 MHz crystal oscillator and then setting up the main clock to 66 MHz. The second function call initializes a general purpose pin named `LED` that is the pin `PC04` to be exact as defined at line 5. The `GPIO_OUTPUT` part of the line states that the `LED` pin will be an output. Making the pin high at line 13 turns the LED on, so in conclusion the job of this software is only to keep the LED burning.

PROJECT STRUCTURE – WHERE THINGS GO?

Aery32 Software Framework provides a complete project structure to start AVR32 development right away. You just start coding and adding your files. The default project directory structure looks like this:

```
projectname/  
  aery32/  
    ...  
  examples/  
    ...  
  board.cpp  
  board.h  
  main.cpp  
  Makefile
```

It is intended that you work under the root directory most of the time as that is the place where you keep adding your .c, .cpp and .h source files. Notice that Aery32 Framework is a C/C++ framework and thus you can write your code in both C and C++. Just put the C code in .c files and C++ code in .cpp files.

2.1 Main source file, main.cpp

The main.cpp source file contains the default main function where to start building your project.

```
1 #include "board.h"  
2 #include <aery32/all.h>  
3  
4 using namespace aery;  
5  
6 int main(void)  
7 {  
8     /* Put your application initialization sequence here */  
9     init_board();  
10    gpio_init_pin(LED, GPIO_OUTPUT);  
11  
12    /* All done. Turn the LED on. */  
13    gpio_set_pin_high(LED);  
14  
15    for(;;) {  
16        /* Put your application code here */  
17    }  
18 }
```

```
19
20     return 0;
21 }
```

2.2 Board specific functions, `board.h` and `board.cpp`

The default board initialization function, `init_board()`, can be found from the `board.cpp` source file. First it sets all the GPIO pins to inputs. Then it configures the board's power manager. Basically by starting the external oscillator `OCS0` and setting the chip's master (or main) clock frequency to its maximum, which is 66 MHz. If you like to change the master clock frequency or want to change the way how the board is initialized, `init_board()` is the place where to do it. In `board.h` you define the board specific function prototypes and supportive `#define` macros. These macros enables a way to do configuration. For example, the LED pin has been defined to be connected to the pin `PC04`. However, keep your `#definitions` sane.

2.3 Aery32 library

The directory called `aery32/` contains the source files of the Aery32 library. The archive of the library (`.a` file) appears in this directory after the first compile process. The `aery32/` subdirectory within the `aery32/` contains the header files of the library. Linker scripts, which are essential files to define the MCU memory structure are placed under the `ldscripts/` directory. Although you can, you should not need to hassle with those files.

2.4 Examples

Aery32 Framework comes with plenty of example programs, which are placed under the `examples/` directory. Every file should *work out of box* when copied over the project main. To test, for example, the LED toggling demo do the following:

In Windows

Open Command Prompt and command:

```
cp examples\toggle_led.cpp main.cpp
make programs
```

The quickest way to access Command Prompt is to press Windows-key and R (Win+R) at the same time, and type `cmd`.

In Linux

Open terminal and:

```
cp examples/toggle_led.cpp main.cpp
make programs
```

The following lines of commands overwrite the present `main.cpp` file with the example and the uploads (or programs) it into the development board. The program starts running immediately.

THE BUILD SYSTEM

Aery32 Framework comes with a powerful Makefile that provides a convenient way to compile the project. It also has targets for chip programming.

To compile the project just command:

```
make
```

When the compilation process is done, binaries will appear under the project's root (`aery32.hex` and `aery32.elf`). These two files are used in chip programming or program uploading, or chip flashing. Whatever you like to call it. In addition to the binaries, assembly listing and file mapping files, have been created. `aery32.lst` and `aery32.map`, respectively.

The program size is also showed at the end of the compile, like this:

```
Program size:
  text   data   bss    dec    hex filename
  3724   1344   4176   9244   241c aery32.elf
    0     5068    0     5068   13cc aery32.hex
```

`.text` correspond the FLASH usage and `.data + .bss` is the total amount of RAM allocation. Note that you have to take the size of the stack (and possibly heap) into account as well.

At runtime, the initialized data is copied to `.bss` during the startup.

Note: By default the project is compiled with `-O2` optimization. If you run into troubles and your program behaves unpredictly on the chip, first try some other level of optimization

```
make reall COPT="-O0 -fdata-sections -ffunction-sections"
```

3.1 Chip programming

To program the chip with the compiled binary type:

```
make program
```

At this point the Makefile attempts to use `batchisp` in Windows and `dfu-programmer` in Linux, so make sure you have those installed. If you also want to start the program immediately type:

```
make program start
```

or in shorter format:

```
make programs
```

If you want to clean the project folder from the binaries call:

```
make clean
```

To recompile all the project files call:

```
make re
```

The above command recompiles only the files from the project root. It does not recompile the Aery32 library, because that would be ridiculous. If you also want to recompile the Aery32 library use `make reall`. There's also `cleanall` that cleans the Aery32 folder in addition to the project's root.

3.2 How to add new source files to the project

New sources files (.c, .cpp and .h) can be added straight into the project's root and the build system will take care of those. If you like to separate your source code into folders, for example, into subdirectory called `my/` then you have to edit the Makefile slightly. After creating the directory, open the Makefile and find the line:

```
SOURCES=$(wildcard *.cpp) $(wildcard *.c)
```

Edit this line so that it looks like this:

```
SOURCES=$(wildcard *.cpp) $(wildcard *.c) $(wildcard my/*.c) $(wildcard my/*.cpp)
```

3.3 Compile with debug statements

There are two additional make targets that helps you in debugging, `make debug` and `make qa`. The most important is:

```
make debug
```

This compiles the project with the debug statements. Use this when you need to do in-system debugging.

For quality assurance check use:

```
make qa
```

This target compiles the project with more pedantic compiler options. It's good to use this every now and then. Particularly when there are problems in your program. This target can also tell you, if your inline functions are not inlined for some reason.

DELAY FUNCTIONS, #INCLUDE <AERY32/DELAY.H>

There are three convenience delay functions that are intended to be used for short delays, from microseconds to milliseconds.

```
delay_us(10); /* wait 10 microseconds */  
delay_ms(500); /* wait half a second */
```

These functions are dependent on the CPU clock frequency that has to be provided via `F_CPU` definition before the `delay.h` header file has been included, like this

```
#define F_CPU 66000000UL  
#include <aery32/delay.h>
```

If `F_CPU` is not defined, you can still use a low level delay function that takes the number of master clock cycles as a parameter

```
delay_cycles(1000); /* wait 1000 master clock cycles */
```

Hint: You can make smaller than 1 us delays with `delay_cycles()`.

4.1 Use RTC for long delays

Realtime counter (RTC) is better for long time delays or countdowns that last minutes, hours, days or even months or years. For example, to toggle the LED every second one can use `rtc_delay_cycles()` function.

```
1 #include <aery32/gpio.h>  
2 #include <aery32/rtc.h>  
3 #include "board.h"  
4  
5 using namespace aery;  
6  
7 int main(void)  
8 {  
9     init_board();  
10    gpio_init_pin(LED, GPIO_OUTPUT);  
11  
12    rtc_init(0, 0xffffffff, 0, RTC_SOURCE_RC);  
13    rtc_enable(false);
```


```
14
15     for(;;) {
16         gpio_toggle_pin(LED);
17         rtc_delay_cycles(57500);
18     }
19
20     return 0;
21 }
```

The application above first initialize the RTC to start counting from zero to 4 294 967 295, which is `0xffffffff` in hexadecimal. The third parameter is a prescaler for the RTC clock, which was set to be the in-built RC clock. The RC clock within the AVR32 UC3A1 works at 115 kHz frequency, but it's frequency is always divided by two when used for RTC. This means that the counter will be incremented every $1/(115000/2)$ second (approx. every 17.4 us).

When initialized, the RTC has to be enabled before it starts counting. This has been done by calling the `rtc_enable()` function. The first parameter indicates whether the interrupts are enabled too. Here we did not use those and thus `false` was passed as a parameter. However, when much longer delays or time calculations are desired, interrupts should be used. Below is an example program that toggles the LED every minute through the RTC interrupt event function, `isrhandler_rtc()`.

```
1  #include <aery32/gpio.h>
2  #include <aery32/intc.h>
3  #include <aery32/rtc.h>
4  #include "board.h"
5
6  using namespace aery;
7
8  void isrhandler_rtc(void)
9  {
10     gpio_toggle_pin(LED);
11     rtc_clear_interrupt(); /* Remember to clear RTC interrupt */
12 }
13
14 int main(void)
15 {
16     init_board();
17     gpio_init_pin(LED, GPIO_OUTPUT|GPIO_HIGH);
18
19     rtc_init(0, 60*115000/2, 0, RTC_SOURCE_RC);
20
21     intc_init();
22     intc_register_isrhandler(&isrhandler_rtc, 1, 0);
23     intc_enable_globally();
24
25     rtc_enable(true);
26
27     for(;;) {
28     }
29
30     return 0;
31 }
```

UC3A0/1 SYSTEM CLOCKS DESCRIBED



UC3A0/1 chips have quite a complex clock system as it can be seen from the figure. At start-up the UC3 runs at its internal RC oscillator that's 115 kHz. This means that the Main clock has been clocked from this RC oscillator and that the CPU frequency equals to 115 kHz. That's because by default the clock domain prescaler has been disabled. This also means that all the other clock domains, that are HSB, PBA and PBB, runs at 115 kHz frequency as well.

5.1 Main clock means the CPU clock

It's important to understand that all the clock domains are derived from the Main (or Master) clock. The main clock can be clocked from couple of other sources in addition to the RC oscillator. It can be clocked from the OSC0 or PLL0. PLL0 clock frequency can equal to its VCO frequency or VCO/2. As the PLL can have a very high clock frequency it's important to set the clock domain prescaler properly, the maximum frequency is 66 MHz. It's also good to know

that CPU and HSB domains must equal each other and that the PBA and PBB frequencies have to be smaller than or equal to CPU.

PLLs can be driven only from the external crystal oscillators and its output can be used, in addition to the Main clock, for the Generic clocks. Generic clocks are multi-purpose clocks. You can use those, for example, to clock your external devices by connecting the clock pin of the device to the proper GPIO pin that can act as an output for the Generic clock. The internal USB and ABDAC peripherals get their clock from the Generic clock module too.

Read more about how to operate with these clocks from the Power Manager within the Modules section.

MODULE FUNCTIONS

Modules are library components that operate with the MCU's internal peripherals. Every module has its own namespace according to the module name. For example, Power Manager has module namespace of `pm_`, Realtime Counter falls under the `rtc_` namespace, etc. To use the module just include its header file. These header files are also named after the module name. So, for example, to include and use functions that operate with the Power Manager include `<aery32/pm.h>`.

6.1 Naming convention and the calling order

The common calling order for modules is the following: 1) initialize, 2) do some extra setuping and after then 3) enable the module. In pseudo code it looks like this

```
module_init();
module_setup_something();
module_enable();
```

The init function may also look like `module_init_something()`, for example, the SPI can be initialized as a master or slave, so the naming convention declares two init functions for SPI module: `spi_init_master()` and `spi_init_slave()`.

If the module has been disabled, by using `module_disable()` function, it can be re-enabled without calling the init or setup functions. Most of the modules can also be reinitialized without disabling it before. For example, general clock frequencies can be changed by just calling the init function again – this is also the quickest way to change the frequency

```
pm_init_gclk(GCLK0, GCLK_SOURCE_PLL1, 1);
pm_enable_gclk(GCLK0);

/* Change the frequency divider */
pm_init_gclk(GCLK0, GCLK_SOURCE_PLL1, 6);
```

If you have read through the MCU datasheet, you may wonder why you cannot set all the possible settings with the initialization and setup functions. This is because these functions set sane default values for those properties. These default values should work for 80-90% of use cases. However, sometimes you may have to fine tune these properties to match your needs. This can be done by bitbanging the module registers after you have called the init or setup function. For example, the SPI chip select baudrate is hard coded to $MCK/255$ within the `spi_setup_npcs()` function. To make SPI bus faster you can bitbang the *SCR_B* bit within *CSR_n* register, where *n* is the NPC_S number.

```
spi_setup_npcs(spi0, 0, SPI_MODE1, 16);
spi0->CSR0.scrb = 32; /* SPI baudrate for the CS0 is now MCK/32 */
```

Note: Modules never take care of pin initialization, except GPIO module that's for this specific purpose. So, for example, when initializing SPI you have to take care of pin configuration!

```
#define SPI0_GPIO_MASK ((1 << 10) | (1 << 11) | (1 << 12) | (1 << 13))
gpio_init_pins(porta, SPI0_GPIO_MASK, GPIO_FUNCTION_A);
```

6.2 Global variables and error handling

Every module declares global shortcut variables to the main registers of the module. For example, the GPIO module declares `porta`, `b` and `c` global pointers to the MCU ports by default. Otherwise, you should have been more verbose and use `&AVR32_GPIO.port[0]`, `&AVR32_GPIO.port[1]` and `&AVR32_GPIO.port[2]`, respectively. Similarly, `pll0` and `pll1` declared in PM module provide quick access to MCU PLL registers etc.

Hint: As `porta`, `b` and `c` are pointers to the GPIO port, you can access its registers with arrow operator, for example, instead of using function `gpio_toggle_pin(AVR32_PIN_PC04)` you could have written `portc->ovrt = (1 << 4);` This is also way how you can set/unset/read/toggle multiple pins at once. Refer to the UC3A0/1 datasheet pages 175–177 for GPIO Register Map.

6.2.1 Error handling

All module functions will return -1 on general error. This will happen most probably because of invalid parameter values. Greater negative return values have a specific meaning and a macro definition in the module's header file. For example, `flashc_save_page()` of Flash Controller may return -2 and -3, which have been defined with E prefixed names `EFLASH_PAGE_LOCKED` and `EFLASH_PROG_ERR`, respectively.

6.3 Analog-to-digital conversion, `#include <aery32/adc.h>`

UC3A0/1 microcontrollers have eight 10-bit analog-to-digital converters. The maximum ADC clock frequency for the 10-bit precision is 5 MHz. For 8-bit precision it is 8 MHz. This frequency is related to the frequency of the Peripheral Bus A (PBA). When initialized a correct prescaler value has to be used. `adc_init()` will check this for you. -1 will be returned, if the clock requirement was not fulfilled.

```
int errno;
errno = adc_init(
    7, /* prescal, adclk = pba_clk / (2 * (prescal+1)) */
    true, /* hires, 10-bit (false would be 8-bit) */
    0, /* shtim, sample and hold time = (shtim + 1) / adclk */
    0 /* startup, startup time = (startup + 1) * 8 / adclk */
);
```

The initialization statement given above, uses the prescaler value 7, so if the PBA clock was 66 MHz, the ADC clock would be 4.125 MHz. After initialization, you have to enable the channels that you like to use for the conversion. This can be done through the masking, so there is use for the good old << bitwise shift operator.

```
if (errno != -1)
    adc_enable(1 << 3); /* enables the channel 3 */
```

Now you can start the conversion. Be sure to wait that the conversion is ready before reading the conversion value.

```
uint16_t result;

adc_start_cnv();
while (adc_isbusy(1 << 3));
result = adc_read_cnv(3);
```

If you only want to read the latest conversion, whatever was the channel, you can omit the channel mask for busy function and read the conversion with another function like this

```
while (adc_isbusy());
result = adc_read_lastcnv();
```

To setup the ADC hardware trigger, call `adc_setup_trigger()` after init


```
adc_setup_trigger(EXTERNAL_TRG);
```

Other possible trigger sources, that can be used for example with the Timer/Counter module, are

- INTERNAL_TRG0
- INTERNAL_TRG1
- INTERNAL_TRG3
- INTERNAL_TRG4
- INTERNAL_TRG5

Note: You always have to call `adc_start_cnv()` individually for every started conversion. If you suspect that your conversions may have overrun, you can check this with the `adc_hasoverrun(chamask)` function. If you omit the channel mask input param, all the channels will be checked, being essentially the same than calling `adc_hasoverrun(0xff)`.

6.4 Flash Controller, `#include <aery32/flashc.h>`



Flash Controller provides low-level access to the chip's internal flash memory, whose structure has been sketched in the figure above. The `init` function of the Flash Controller sets the flash wait state and the state of the sense amplifiers.

```
flashc_init(FLASH_1WS, true);
```

Warning: Setting up the correct flash wait state is extremely important! If CPU clock speed is higher than 33 MHz you have to use one wait state for flash. Otherwise you can use zero wait state, `FLASH_0WS`. Note that this has to be set correctly even if the flash read and write operations, described below, are not used.

6.4.1 Read and write operations

Flash memory is accessed via pages that are 512 bytes and only 512 bytes long. This means that you have to make sure that your page buffer is large enough to read and write pages, like this

```
#include <cstring>

char buf[512];
flashc_read_page(FLASH_LAST_PAGE, buf); /* Read the last page to separate page buffer */
strcpy(buf, "foo"); /* Save string "foo" to page buffer */
flashc_save_page(FLASH_LAST_PAGE, buf); /* Write page buffer back to flash */
```

You can also read and write values with different types as long as the page buffer size is that 512 bytes.

```
extern "C" #include <inttypes.h>

uint16_t buf16[256];
uint32_t buf32[128];
```

After saving the page it can be locked to prevent write or erase sequences.

```
flashc_lock_page(0); /* Locks the first page, number 0 */
```

Locking is performed on a per-region basis, so the above statement does not lock only page zero, but all pages within the region (16 pages per region). To unlock the page call

```
flashc_unlock_page(0);
```

There are also functions that takes the region as an input param, `flashc_lock_preg()` and `flashc_unlock_preg()`. Furthermore, there is a function to check if the page is empty

```
flashc_isempty(0);
```

Warning: The uploaded program is also stored into the flash, so it is possible to overwrite it by using the Flash controller. The best practice for flash programming, is starting from the top. `FLASH_LAST_PAGE` macro definition gives the number of the last page in the flash. For 128 KB flash this would be 255.

6.5 General Periheral Input/Output, `#include <aery32/gpio.h>`

To initialize any pin to be output high, there is a oneliner which can be used

```
gpio_init_pin(AVR32_PIN_PC04, GPIO_OUTPUT|GPIO_HIGH);
```

The first argument is the GPIO pin number and the second one is for options. For 100 pin Atmel AVR32UC3, the GPIO pin number is a decimal number from 0 to 69. Fortunately, you do not have to remember which number represent what port and pin. Instead you can use predefined aliases as it was done above with the pin PC04 (5th pin in port C if the PC00 is the 1st).

The available pin init options are:

- GPIO_OUTPUT
- GPIO_INPUT
- GPIO_HIGH
- GPIO_LOW
- GPIO_FUNCTION_A
- GPIO_FUNCTION_B
- GPIO_FUNCTION_C
- GPIO_FUNCTION_D
- GPIO_INT_PIN_CHANGE
- GPIO_INT_RAISING_EDGE
- GPIO_INT_FALLING_EDGE
- GPIO_PULLUP
- GPIO_OPENDRAIN
- GPIO_GLITCH_FILTER
- GPIO_HIZ

These options can be combined with the pipe operator (boolean OR) to carry out several commands at once. Without this feature the above oneliner should be written with two lines of code:

```
gpio_init_pin(AVR32_PIN_PC04, GPIO_OUTPUT);
gpio_set_pin_high(AVR32_PIN_PC04);
```

Well now you also know how to set pin high, so you may guess that the following function sets it low

```
gpio_set_pin_low(AVR32_PIN_PC04);
```

and that the following toggles it

```
gpio_toggle_pin(AVR32_PIN_PC04);
```

and finally it should not be surprise that there is a read function too

```
state = gpio_read_pin(AVR32_PIN_PC04);
```

But before going any further, let's quickly go through those pin init options. FUNCTION_A, B, C and D assign the pin to the specific peripheral function, see datasheet pages 45–48. INT_PIN_CHANGE, RAISING_EDGE and FALLING_EDGE enables interrupt events on the pin. Interrupts are triggered on pin change, at the rising edge or at falling edge, respectively. GPIO_PULLUP connects pin to the internal pull up resistor. GPIO_OPENDRAIN in turn makes the pin operate as an open drain mode. This mode is generally used with pull up resistors to guarantee a high level on line when no driver is active. Lastly GPIO_GLITCH_FILTER activates the glitch filter and GPIO_HIZ makes the pin high impedance.

Usually you want to init several pins at once – not only one pin. This can be done for the pins that have the same port.

```
gpio_init_pins(porta, 0xffffffff, GPIO_INPUT); /* initializes all pins input */
```

The first argument is a pointer to the port register and the second one is the pin mask.

Note: Most of the combinations of GPIO init pin options do not make sense and have unknown consequences.

6.5.1 Local GPIO bus

AVR32 includes so called local bus interface that connects its CPU to device-specific high-speed systems, such as floating-point units and fast GPIO ports. To enable local bus call

```
gpio_enable_localbus();
```

When enabled you have to operate with *local* GPIO registers. That is because, the convenience functions described above does not work local bus. To ease operating with local bus Aery32 GPIO module provides shortcuts to local ports by declaring `lporta`, `b` and `c` global pointers. Use these to read and write local port registers. For example, to toggle pin through local bus you can write

```
lporta->ovrt = (1 << 4);
```

Note: CPU clock has to match with PBB clock to make local bus functional

To disable local bus and go back to normal operation call

```
gpio_disable_localbus();
```

6.6 Interrupt Controller, `#include <aery32/intc.h>`

Before enabling interrupts define and register your interrupt service routine (ISR) functions. First write ISR function as you would do for any other functions

```
void myisr_for_group1(void) {  
    /* do something */  
}
```

Then register this function

```
intc_register_isrhandler(&myisr_for_group1, 1, 0);
```

Here the first parameter is a function pointer to your `myisr_for_group1()` function. The second parameter defines the which interrupt group calls this function and the last one tells the priority level.

Hint: Refer Table 12-3 (Interrupt Request Signal Map) in datasheet page 41 to see what peripheral belongs to which group. For example, RTC belongs to group 1.

When all the ISR functions have been declared it is time to initialize interrupts. Use the following init function to do all the magic

```
intc_init();
```

After initialization you can enable and disable interrupts globally by using these functions

```
intc_enable_globally();
```

```
intc_disable_globally();
```

6.7 Power Manager, `#include <aery32/pm.h>`

Power Manager controls integrated oscillators and PLLs among other power related things. By default the MCU runs on the internal RC oscillator (115 kHz). However, it's often preferred to switch to the higher CPU clock frequency, so one of the first things what to do after the power up, is the initialization of oscillators. Aery32 Development Board has 12 MHz crystal oscillator connected to the OSC0. This can be started as

```
pm_start_osc(
    0, /* oscillator number */
    OSC_MODE_GAIN3, /* oscillator mode, see datasheet p.74 */
    OSC_STARTUP_36ms /* oscillator startup time */
);
pm_wait_osc_to_stabilize(0);
```

When the oscillator has been stabilized it can be used for the master/main clock

```
pm_select_mck(MCK_SOURCE_OSC0);
```

Now the CPU runs at 12 MHz frequency. The other possible source selections for the master clock are:

- MCK_SOURCE_OSC0
- MCK_SOURCE_PLL0
- MCK_SOURCE_PLL1

6.7.1 Use PLLs to achieve higher clock frequencies

Aery32 devboard can run at 66 MHz its fastest. To achieve these higher clock frequencies one must use PLLs. PLL has a voltage controlled oscillator (VCO) that has to be initialized first. After then the PLL itself can be enabled.

Important: PLL VCO frequency has to fall between 80–180 MHz or 160–240 MHz with high frequency disabled or enabled, respectively. From these rules, one can realize that the smallest available PLL frequency is 40 MHz (the VCO frequency can be divided by two afterwards).

```
pm_init_pllvco(
    pll0, /* pointer to pll address */
    PLL_SOURCE_OSC0, /* source clock */
    11, /* multiplier */
    1, /* divider */
    false /* high frequency */
);
```

- If $div > 0$ then $f_{vco} = f_{src} * mul / div$
- If $div = 0$ then $f_{vco} = 2 * mul * f_{src}$

The above initialization sets PLL VCO frequency of PLL0 to 132 MHz – that's $12 \text{ MHz} * 11 / 1 = 132 \text{ MHz}$. After then PLL can be enabled and the VCO frequency appears on the PLL output. Remember that you can now also divide VCO frequency by two.

```
pm_enable_pll(pll0, true /* divide by two */); /* 132 MHz / 2 = 66 MHz */
pm_wait_pll_to_lock(pll0);
```

Finally one can change the master clock (or main clock) to be clocked from the PLL0 that's 66 MHz.

```
pm_select_mck(MCK_SOURCE_PLL0);
```

6.7.2 Fine tune the CPU and Periheral BUS frequencies

By default the clock domains, that are CPU and the Peripheral Busses (PBA and PBB) equal to the master clock. To fine tune these clock domains, the PM has a 3-bit prescaler, which can be used to divide the master clock, before it has been used for the specific domain. Using the prescaler you can choose the CPU clock between the OSC0 frequency

and 40 MHz, that was the lower limit of the PLL. Assuming that the master clock was 66 MHz, the following function call changes the CPU and the bus frequencies to 33 MHz:

```
pm_setup_clkdomain(1, CLKDOMAIN_ALL);
```

The first parameter defines the prescaler value and the second one selects the clock domain which to set up. Here all the domains are set to equal. The formula is $f_{mck} / (2^{\text{prescaler}})$. With the prescaler selection 0, the prescaler block will be disabled and the selected clock domain equals to the master clock that was the default setting.

The possible clock domain selections are

- CLKDOMAIN_CPU
- CLKDOMAIN_PBA
- CLKDOMAIN_PBB
- CLKDOMAIN_ALL

Important: PBA and PBB clocks have to be less or equal to CPU clock. Moreover, the flash wait state has to be taken into account at this point. If the CPU clock is over 33 MHz, the Flash controller has to be initialized with one wait state, like this `flashc_init(FLASH_1WS, true)`. If the CPU clock speed is less or equal than 33 MHz, zero wait state is the correct setting for the flash.

Hint: You can combine the clock domain selections with the pipe operator, like this `CLKDOMAIN_CPU|CLKDOMAIN_PBB`. With this selection the PBA clock frequency won't be changed, but the CPU and PBB will be set up accordingly.

6.7.3 General clocks

PM can generate dedicated general clocks. These clocks can be assigned to GPIO pins or used for internal peripherals such as USB that needs 48 MHz clock to work. To offer this 48 MHz for the USB peripheral, you have to initialize either of the PLLs to work at 96 MHz frequency. As the PLL0 is commonly used for the master clock, PLL1 has been dedicated for general clocks. First initialize the VCO frequency and then enable the PLL

```
pm_init_pll_vco(pll1, PLL_SOURCE_OSC0, 16, 1, true); /* f_pll1_vco = 192 MHz */
pm_enable_pll(pll1, true); /* f_pll1 = 96 MHz */
pm_wait_pll_to_lock(pll1);
```

After then init and enable the USB generic clock

```
pm_init_gclk(
    GCLK_USBB, /* generic clock number */
    GCLK_SOURCE_PLL1, /* clock source for the generic clock */
    1 /* divider */
);
pm_enable_gclk(GCLK_USBB);
```

- If $div > 0$ then $f_{gclk} = f_{src} / (2 * div)$
- If $div = 0$ then $f_{gclk} = f_{src}$

There are five possible general clocks to be initialized:

- GCLK0
- GCLK1
- GCLK2
- GCLK3
- GCLK_USBB

- GCLK_ABDAC

GCLK_ABDAC is for Audio Bitstream DAC, GCLK0, GCLK1, etc. can be attached to GPIO pin, so that you can easily clock external devices. For example, to set generic clock to be at the output of GPIO pin, first init the desired GPIO pin appropriately and then enable the generic clock at this pin. You can do this, for example, to check that USB clock enabled above is correct

```
gpio_init_pin(AVR32_PIN_PB19, GPIO_FUNCTION_B);
pm_init_gclk(GCLK0, GCLK_SOURCE_PLL1, 1);
pm_enable_gclk(GCLK0);
```

Hint: Generic clock can be changed when its running by just initializing it again. You do not have to disable it before doing this and you do not have to enable it again.

6.7.4 Save power and use only the peripherals that you need

By default all modules are enabled. You might be interested in to disable modules you are not using. This can done via the peripheral clock masking. The following example disables clocks from the TWI, PWM, SSC, TC, ABDAC and all the USART modules

```
#define PBAMASK_DEFAULT 0x0F
pm->pbamask = PBAMASK_DEFAULT;
```

Remember to wait when the change has been completed

```
while (!(pm->isr & AVR32_PM_ISR_MSKRDY_MASK));
/* Clocks are now masked according to (CPU/HSB/PBA/PBB)_MASK
 * registers. */
```

6.7.5 How much is the clock?

Sometimes the current clock frequencies has to be checked programmatically. To get the main clock use the `pm_get_fmck()` function

```
main_hz = pm_get_fmck();
```

Respectively, the clock domains can be fetched like this

```
cpu_hz = pm_get_fclkdomain(CLKDOMAIN_CPU);
pba_hz = pm_get_fclkdomain(CLKDOMAIN_PBA);
pbb_hz = pm_get_fclkdomain(CLKDOMAIN_PBB);
```

These functions assume that OSC0 and OSC1 frequencies are 12 MHz and 16 MHz, respectively. If other oscillator frequencies are used, change the default values by editing CXXFLAGS in `aery32/Makefile`.

6.8 Pulse Width Modulation, #include <aery32/pwm.h>

Start by initializing the PWM channel which you want to use

```
pwm_init_channel(2, MCK);
```

The above initializer sets channel's two PWM frequency equal to the main clock and omits the duration and period for default values. The default values for the duration and period are 0 and 0xFFFFF, respectively. If you like to start the channel with different values, you could have defined those too like this

```
pwm_init_channel(2, MCK, 50, 100);
```

This gives you duty cycle of 50% from start. The maximum value for both the duration and the period is 0xFFFFF. It is also worth noting that when the period is set to its maximum value, the channel's duty cycle can be set most accurately.

The above initializers set the channel's frequency equal to the main clock. The other possible frequency selections are

- MCK_DIVIDED_BY_2
- MCK_DIVIDED_BY_4
- MCK_DIVIDED_BY_8
- MCK_DIVIDED_BY_16
- MCK_DIVIDED_BY_32
- MCK_DIVIDED_BY_64
- MCK_DIVIDED_BY_128
- MCK_DIVIDED_BY_256
- MCK_DIVIDED_BY_512
- MCK_DIVIDED_BY_1024
- PWM_CLKA
- PWM_CLKB

PWM_CLKA and PWM_CLKB are two extra PWM clock sources. The difference to other sources is an additional linear divider block that comes after the MCK prescaler. To initialize the divider block for the PWM_CLKA and PWM_CLKB call

```
pwm_init_divab(MCK, 10, MCK_DIVIDED_BY_2, 10);
```

Now PWM_CLKA has the frequency of $MCK / 10$ Hz and PWM_CLKB is $MCK / 2 / 10$ Hz. If you don't care about CLKB, you can omit the last two of the parameters like this

```
pwm_init_divab(MCK, 10);
```

If the divider of PWM_CLKA or PWM_CLKB has been set zero, then the PWM clock will equal to the MCK, MCK_DIVIDED_BY_2, etc. Whatever was the chosen prescaler. So it does not make sense to set the divider of the extra PWM clock zero, because then you don't have any extra clock selection.

6.8.1 Setting up PWM mode

Before enabling the initialized PWM channel or channels, you may like to setup the channel mode to set PWM alignment and polarity

```
pwm_setup_chamode(2, LEFT_ALIGNED, START_HIGH);
```

The alignment (left or center, LEFT_ALIGNED and CENTER_ALIGNED, respectively) defines the shape of PWM function, see datasheet page 680. The polarity defines the polarity of the duty cycle. With START_HIGH, the duty cycle is 100% when *duration / period* of the PWM function gives 1. With START_LOW you would get 100% duty cycle when the *duration / period* is 0.

6.8.2 Enabling and disabling the PWM

PWM is enabled and disabled by channels. Several channels can be enabled at once to get synchronized output. To enable channels two and four call

```
pwm_enable((1 << 2) | (1 << 4));
```

Same goes for the disabling the channels. The following call will disable the channel two

```
pwm_disable(1 << 2);
```

The parameter of the enable and disable functions is a bitmask of the channels to be enabled or disabled. There is also function to check if the channel has been enabled already. The following snippet will do something if the channel two was already enabled

```
if (pwm_isenabled(1 << 2)) {
    /* Do something */
}
```

6.8.3 Modulating the PWM output waveform

You can modulate the PWM output waveform when it is active by changing its duty cycle like this

```
pwm_update_dutycl(2, 0.5);
```

The above function call will update the channel's two duty cycle to 50%. In case you want to specify completely new values for the period and duration use these two functions

```
pwm_update_period(2, 0x1000);
pwm_update_duration(2, 0x10);
```

Furthermore, to keep PWM output at the desired state for the amount of periods, before changing its state again, use the wait function. This also allows you to do updates from the beginning of the next period and thus avoiding to overwrite the value too soon. For example, to wait 100 periods on channel two call

```
pwm_wait_periods(2, 100);
```

With the combination of the update functions and the wait function, you can make a smoothly blinking LED, just like this

```
uint8_t channel = 2;
uint32_t duration = 0;
uint32_t period = 0x1000;

for (;;) {
    for (; duration < period; duration++) {
        pwm_update_duration(channel, duration);
        pwm_wait_periods(channel, 500);
    }
    for (; duration > 0; duration--) {
        pwm_update_duration(channel, duration);
        pwm_wait_periods(channel, 500);
    }
}
```

Note: Duration has to be smaller or equal to period.

6.9 Real-time Counter, #include <aery32/rtc.h>

Real-time counter is for accurate real-time measurements. It enables periodic interrupts at long intervals and the measurement of real-time sequences. RTC has to be init to start counting from the chosen value to the chosen top value. This can be done in this way

```
rtc_init(  
    RTC_SOURCE_RC, /* source oscillator */  
    0,             /* prescaler for RTC clock */  
    0,             /* value where to start counting */  
    0xffffffff    /* top value where to count */  
);
```

The available source oscillators are:

- RTC_SOURCE_RC (115 kHz RC oscillator within the AVR32)
- RTC_SOURCE_OSC32 (external low-frequency xtal, not assembled in Aery32 Devboard)

When initialized, remember to enable it too

```
rtc_enable(false);
```

The boolean parameter here, tells if the interrupts are enabled or not. Here the interrupts are not enabled so it is your job to poll RTC to check whether the top value has been reached or not.

6.10 Serial Peripheral Bus, #include <aery32/spi.h>

AVR32 UC3A1 includes to separate SPI buses, SPI0 and SPI1. To initialize SPI bus it is good practice to define pin mask for the SPI related pins. Referring to datasheet page 45, SPI0 operates from PORTA:

- PA07, NPCS3
- PA08, NPCS1
- PA09, NPCS2
- PA10, NPCS0
- PA11, MISO
- PA12, MOSI
- PA13, SCK

So let's define the pin mask for SPI0 with NPCS0 (Numeric Processor Chip Select, also known as slave select or chip select):

```
#define SPI0_GPIO_MASK ((1 << 10) | (1 << 11) | (1 << 12) | (1 << 13))
```

Next we have to assign these pins to the right peripheral function that is FUNCTION A. To do that use pin initializer from GPIO module:

```
gpio_init_pins(porta, SPI0_GPIO_MASK, GPIO_FUNCTION_A);
```

Now the GPIO pins have been assigned appropriately and we are ready to initialize SPI0. Let's init it as a master:

```
spi_init_master(spi0);
```

The only parameter is a pointer to the SPI register. Aery32 declares `spi0` and `spi1` global pointers by default.

Hint: If the four SPI CS pins are not enough, you can use CS pins in multiplexed mode (of course you need an external multiplexer circuit then) and expand number of CS lines to 16. This can be done by bitbanging PCSDEC bit in SPI MR register after the initialization:

```
spi_init_master(spi0);
spi0->MR.pcsdec = 1;
```

When the SPI peripheral has been initialized as a master, we still have to setup its CS line 0 (NPCS0) with the desired SPI mode and shift register width. To set these to SPI mode 0 and 16 bit, call the `npcs` setup function with the following parameters

```
spi_setup_npcs(spi0, 0, SPI_MODE0, 16);
```

The minimum and maximum shift register widths are 8 and 16 bits, respectively, but you can still *use arbitrary wide transmission*.

Hint: Chip select baudrate is hard coded to MCK/255. To make it faster you can bitbang the SCRIB bit in the CSRX register, where X is the NPCS number:

```
spi_setup_npcs(spi0, 0, SPI_MODE0, 16);
spi0->CSR0.scrb = 32; /* baudrate is now MCK/32 */
```

Hint: Different CS lines can have separate SPI mode, baudrate and shift register width.

Now we are ready to enable SPI peripheral

```
spi_enable(spi0);
```

There's also function for disabling the desired SPI peripheral `spi_disable(spi0)`. To write data into SPI bus use the `transmit` function

```
uint16_t rd;
rd = spi_transmit(spi0, 0, 0x55, true); /* writes 0x55 to SPI0, NPCS0 */
```

Hint: `spi_transmit()` writes and reads SPI bus simultaneously. If you only want to read data, just ignore write data by sending dummy bits.

Here is the complete code for the above SPI initialization and transmission:

```
1 #include <aery32/gpio.h>
2 #include <aery32/spi.h>
3 #include "board.h"
4
5 using namespace aery;
6
7 #define SPI0_GPIO_MASK ((1 << 10) | (1 << 11) | (1 << 12) | (1 << 13))
8
9 int main(void)
10 {
11     uint16_t rd; /* received data */
12
13     init_board();
```

```
14
15     gpio_init_pins(porta, SPI0_GPIO_MASK, GPIO_FUNCTION_A);
16     spi_init_master(spi0);
17     spi_setup_npcs(spi0, 0, SPI_MODE0, 16);
18     spi_enable(spi0);
19
20     for (;;) {
21         rd = spi_transmit(spi0, 0, 0x55, true);
22     }
23
24     return 0;
25 }
```

6.10.1 Sending arbitrary wide SPI data

The last parameter, `islast`, of the `spi_transmit()` function indicates for the SPI whether the current transmission was the last one. If `true`, chip select line rises immediately when the last bit has been written. If `islast` is defined `false`, CS line is left low for the next transmission that should occur immediately after the previous one. This feature allows SPI to operate with arbitrary wide shift registers. For example, to read and write 32 bit wide SPI data you can do this:

```
uint32_t rd;

spi_setup_npcs(spi0, 0, SPI_MODE0, 8);

rd = spi_transmit(spi0, 0, 0x55, false);
rd |= spi_transmit(spi0, 0, 0xf0, false) << 8;
rd |= spi_transmit(spi0, 0, 0x0f, true) << 16; /* Complete. Asserts the chip select */
```

CONTRIBUTOR'S GUIDE

The development of Aery32 Framework happens in GitHub, which is a web-based hosting service that use the Git revision control system. To contribute the code you have to have a GitHub account. After that you can [fork](#) Aery32 repository and start contribute by sending [pull request](#).

GitHub has a good beginners guide about [how to set up Git in Windows](#).

7.1 Sending a pull request (creating a patch)

Fixes are sent as [pull requests](#). Before you start fixing the Aery32 library, create a new branch and code your patch in this new branch. If there is a reported issue you are fixing, name the branch according to the GitHub issue number, e.g. gh-02.

The benefit of this approach is that you can have plenty of fixes which are isolated from each others, especially from the master branch.

7.2 Coding standards

Follow Linux kernel coding style.

```
#include <stdbool.h>
#include <avr32/io.h>

typedef struct Foo Foo;
typedef struct Bar Bar;

struct Foo {
    Bar *bar;
};

struct Bar {
    Foo *foo;
};

/**
 * Initializes io pins (define the function briefly at the first line)
 * \param allinput If true all pins initialized as inputs
 *
 * More detailed description comes here. Remember to use param names
 * within the function prototypes too.
 */
```

```
void init_io(bool allinput);

void init_io(bool allinput)    /* Layout functions like this */
{
    int i;

    /* Use space between the syntactic keywords and opening parenthesis */
    for (i = 0; i < 2; i++) {
        AVR32_GPIO.port[i].gpers = 0xffffffff;

        if (allinput == 0)    /* Do not use curly braces if not needed */
            AVR32_GPIO.port[i].oders = 0xffffffff;
        else
            AVR32_GPIO.port[i].oderc = 0xffffffff;
    }
}

int main(void)
{
    char *c;    /* not char* c */
    Foo foo;
    Bar bar;

    bar.foo = &foo;
    /*
     * This is multiline comment that reminds you not to use compound literals
     * in Aery32 library, because avr32-g++ does not support those.
     *
     * Example of the use of compound literal:
     * bar = (Bar) {.foo = &foo};
     */

    for (;;) {    /* This is how infinite loops are written */
    }

    return 0;
}
```

7.3 Writing the documentation

The documentation is constructed by Sphinx. Sphinx is a Python documentation generator but works fine for C as well.

The source files of this documentation are located at the separate GitHub repository, <https://github.com/aery32/aery32-refguide>. To build local html version of this documentation use make:

```
make html
```

The following commands assume you have Sphinx installed – if not, see the installation instructions below. Now browse to `source/` directory and open the `index.rst`. This is the master document serving as a welcome page and “*table of contents tree*”. To edit these source files just open the file in your favorite editor and be sure to edit in UTF-8 mode. To understand reSt syntax start from <http://sphinx.pocoo.org/rest.html>.

7.3.1 Installing Sphinx

In Windows

Case 1: I do have Python already installed

If you do have Python installed already, then you likely have setuptools installed as well. In this case install Sphinx with `easy_install`. Fire your command prompt (Win+R cmd) and command:

```
easy_install -U Sphinx
```

Otherwise follow steps below to install Python first and then Sphinx.

Case 2: I don't have Python installed

Note: We do not install setuptools here and thus do not use `easy_install` to install Sphinx. However you will get it installed along Sphinx installer and it is recommended to use it later when installing other Python packages.

- Create temporary directory (e.g. `myfoo`) where to download the following things:
 - Python 2.7.x from <http://python.org/download/>
 - Sphinx 1.1.2 from <http://pypi.python.org/pypi/Sphinx>
- When the both download processes have been completed, you should have these two files:
 - `python-2.7.2.msi` or `python-2.7.2.amd64.msi` if you downloaded 64-bit version
 - `Sphinx-1.1.2.tar.gz`
- First install Python by double clicking Python installer
- After successful installation of Python, untar `Sphinx-1.1.2.tar.gz` into temporary directory
 - The extraction process creates the `Sphinx-1.1.2` directory, change to that directory and double click setup to install Sphinx
 - Once the Sphinx installation is complete, you will find `sphinx-xxx` executables in your Python Scripts sub-directory, `C:\Python27\Scripts`. Be sure to add this directory to your PATH environment variable. As you can see, this directory includes now also `easy_install` executable, which you should use later to install other Python packages.
- You can now remove the temporary directory

INDICES AND TABLES

- *genindex*
- *modindex*
- *search*